





**ERSATZTEILLISTE**  
*SPARE PARTS LIST*  
**LISTE DES PIÈCES DE RECHANGE**  
*ELENCO DEI PEZZI DI RICAMBIO*

**Steuerelemente (Pneumatisch),  
Control device (pneumatic),  
Élément de commande  
(pneumatique),  
Elemento di comando  
(pneumatico)**




**EL-100078**




D  
E  
F  
I

Halter für Signalgeber Art. Nr. 45428  
*Proximity Switch holder art. num. 45428*  
 Support pour générateur de signal Réf. unité 45428  
*Supporto per trasduttore segnali Art. No. 45428*




D  
E  
F  
I

Steuerelemente Stop/Start Art. Nr. 45989  
*Stop/start device art. num. 45989*  
 Élément de pilotage stop/start Réf. unité 45989  
*Elemento di comando Art. No. 45989*




D  
E  
F  
I

Steuerelemente Stop/Start Art. Nr. 90419  
*Stop/Start Device art. num. 90419*  
 Élément de pilotage stop/start Réf. unité 90419  
*Elemento di comando stop/start Art. No. 90419*




D  
E  
F  
I

Steuerelemente Stop/Start Art. Nr. 90786  
*Stop/Start Device art. num. 90786*  
 Élément de pilotage stop/start Réf. unité 90786  
*Elemento di comando stop/start Art. No. 90786*



D  
E  
F  
I

Stop/Start für Kurve innen Art. Nr. 91518KI  
*Stop/start device (inside curve) art. num. 91518KI*  
 Élément de commande stop/start Réf. unité 91518KI  
*Elementi di comando stop/start Art. No. 91518KI*



D  
E  
F  
I

Stop/Start für Kurve aussen Art. Nr. 91518KA  
*Stop/start device (outside curve) art. num. 91518KA*  
 Élément de commande stop/start Réf. unité 91518KA  
*Elementi di comando stop/start Art. No. 91518KA*